

NATIONAL WINDOW FILM

PO Box 272 Bedminster NJ 07921 Main 908.396.2020
Mobile 917.609.4757 NationalWindowFilm.com



CLEANING INSTRUCTIONS

Commercial

A professional cleaning service may not be familiar with the precautions needed to CLEAN Bird Divert Markers UV absorbing/reflective dot matrix properly.

*It is **important** to inform them that you have had Bird Divert installed and precautions should be taken to protect your investment.*

*Cleaning companies generally use microfiber or sheepskin type pads for scrubbing, but they should be made aware not to use, **steel wool, or abrasive scrubpads**, since these may scratch the surface of the Markers*

When cleaning a large number of windows, professional window cleaners tend to squeegee the glass to remove excess water. If any residue collects around the dot matrix. Use a microfiber to remove residual water.

Ammonia is not to be used

By following these simple instructions, you will protect and the benefits of Bird Divert Markers UV absorbing/reflective dot matrix Marker installation for many years to come.

Residential

When cleaning the Bird Divert Markers surface, always remove as much abrasive dirt as possible without touching the surface. Ideally this would involve thoroughly cleaning the surface with a mild soap and water.

Dirt particles that rest on the matrix surface may cause scratches if not removed

Spray the surface with soapy water and using a soft rubber squeegee making overlapping passes to avoid streaking.

Follow up with a dry cotton or microfiber towel wiping the surface dry.

*If a towel is used to wipe the entire window, be certain the towel is **dry and free from dirt** prior to wiping the film surface.*

